




F007JD PARTS LIST FOR UTG(UTH) GROUP P.1/12



F007JD PARTS LIST FOR UTG(UTH) GROUP P.2/12



F007JD PARTS LIST FOR UTG(UTH) GROUP P.3/12




FOR F007J/F007JD/F858J/F858JD
 * USE FOR F007JD/F858JD

☐ FOR H牌馬達
 ☐ FOR P牌馬達

10/11/03

F007JD PARTS LIST FOR UTG(UTH) GROUP P.4/12



- ① LIFT PRESSER FOOT
- ② LOOP TRIMMER
- ③ TOP CUTTER (WIPER)

- FOR H牌馬達
- FOR P牌馬達

F007JD PARTS LIST FOR UTG(UTH) GROUP P.5/12


A

B

C

D

E



- TXXXXX-A
- ▣ TXXXXX-A

F007JD PARTS LIST FOR UTG(UTH) GROUP P.6/12


A

B

C

D

E



1

2

3

4


5

FOR F007JD/F858JD

□ FOR H牌馬達 (HVP-20)

10/07/01

F007JD PARTS LIST FOR UTG(UTH) GROUP P.7/12



F007JD PARTS LIST FOR UTH-J GROUP P.8/12

A


B

C

D

E

FOR LEFT SIDE



F007JD PARTS LIST FOR UTG-J GROUP P.9/12


A

B

C

D

E



F007JDPARTS LIST FOR UTG(UTH) GROUP P.10/12


A

B


C

D

E



F007JD PARTS LIST FOR UTG(UTH) GROUP P.11/12




FOR F007JD/C007JD/F858JD/C858JD

FOR H牌馬達 (HVP-70)


10/07/01

F007JDPARTS LIST FOR UTG(UTH) GROUP P.12/12




A
B
C
D
E


F007JD PARTS LIST FOR UTJ-J(UTK-J) GROUP P.1/12



F007JD PARTS LIST FOR UTJ-J(UTK-J) GROUP P.2/12



F007JD PARTS LIST FOR UTJ-J(UTK-J) GROUP P.3/12



1 FOR F007J/F007JD/F858J/F858JD

2 FOR H牌馬達
3 FOR P牌馬達

10/07/01

F007JD PARTS LIST FOR UTJ(UTK) GROUP P.4/12


A

B

C

D

E



FOR F007J/F007JD/F858J/F858JD

*USE FOR F007JD/F858JD

FOR H牌馬達

10/11/03

F007JD PARTS LIST FOR UTJ(UTK) GROUP P.5/12



A

B

C

D

E



□ UT226D
□ UT226P

TO WIPER

UT763

*SM630

*CP112

UT534

TO UNDER TRIMMER

□ UT103E
□ UT103P

TO SAFETY S.W

TO PRESSER FOOT


□ UT548K

1 FOR F007JD/F858JD
2 *USE FOR UTJ

3 □ FOR H牌馬達 (HVP-70)
4 □ FOR P牌馬達

5 10/11/25


F007JD PARTS LIST FOR UTJ(UTK) GROUP P.6/12



1 FOR F007JD/F858JD
 *USE FOR UTJ

2 FOR H牌馬達 (HVP-20)
 3 FOR P牌馬達

F007JD PARTS LIST FOR UTJ-J(UTK-J) GROUP P.7/12



F007JD PARTS LIST FOR UTJ-J(UTK-J) GROUP P.8/12


A

B

C


D

E



UTK/UTS 系列

UT218J-A1



F007JD PARTS LIST FOR UTJ-J(UTK-J) GROUP P.9/12

A

B

C

D

E

MA04J

UT753-A

UT750

SM4802

WK21
NM440

SM411

UT752

UT763

UT232

SM135
WK09

UT756

SM471

NM300

UT755

UT757

UT754

UT753

SM432

UT751

WM400

WK05

WM110

SM135

UT758

SM036

SM031

UT759

SM035

UT762

UT761

UT760

SM035

SM001

UT763-A=UT753-A+UT763+UT232+NM300+SM411

1

2

3

4

5

F007JD PARTS LIST FOR UTJ-J(UTK-J) GROUP P.10/12


A

B


C

D

E



F007JD PARTS LIST FOR UTJ-J(UTK-J) GROUP P.11/12



1 FOR F007JD/C007JD/F858JD/C858JD

3 FOR H牌馬達 (HVP-70)

10/07/01

F007JD PARTS LIST FOR UTJ-J(UTK-J) GROUP P.12/12

